

Furniture Wall Mounting & Fixing Guide



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



Tips & Tricks

If you have any doubts about using the correct plug for your wall, please seek professional advice from a qualified tradesperson.


Failure of the product due to using incorrect fixings is the responsibility of the installer. Make sure that the hardware used is suitable for supporting your unit. If you are unsure, please select a larger screw and wall plug.

- ✓ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ✓ Take extra care when drilling high walls, ceiling and ceramic tiles. Drill the hole horizontally. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ✓ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.

NOTE: Supplied wall plugs are only suitable for use in masonry walls.


Types Of Walls

Walls are constructed from different materials. It is important that you use the appropriate wall fixings for your wall type. Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone, plaster or wood. Wood screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc. Refer to User Manual for clarification.